

# Wall Sensor Selection

## Analog wall sensor PL-RSF



- Used with any M2000 or C1000 controller
- Wired using standard #18/3 LVT thermostat wire
- 10K Thermistor input

## Digital wall sensors T1000 / T500 / T200



- Works **ONLY** with ProLon VAV (C1000 VAV or VC2000) and HPS controllers using RS485 communication
- Wired with either #18/4 LVT thermostat or Cat5e / RJ-45 network cable
- Configurable aux. input for remote, averaging or in floor slab temperature sensing (T1000 only)